



The Voluntary Emissions Control Action Programme



BEST AVAILABLE TECHNIQUE

for emptying 500-1000 kg bags containing polymer additives



1

Ensure the ventilation system is running.
Mount the big bag above the Hopper.



2

Open bottom closures.



3

Secure the bag to the Hopper to prevent spillage.



4

Product should discharge by gravity.



5

Elongate the bag by raising it slightly.



6

Shake all four corners of the bag vigorously as needed to minimize residue.

Take care that the empty packaging is folded carefully and packed into another bag for disposal. Tightly close the bag between uses. When full, close and seal the outer bag and place in a shipping container for proper disposal, such as incineration or controlled landfill.



For further information:

Contact the VECAP Product Stewardship Team at info@vecap.info or visit www.vecap.info

VECAP is a voluntary initiative of member companies of the European Flame Retardants Association (EFRA) together with the industry's global organisation, the Bromine Science and Environmental Forum (BSEF).