



# BEST AVAILABLE TECHNIQUE



for emptying 500-1000 kg bags containing polymer additives

## THE VOLUNTARY EMISSIONS CONTROL ACTION PROGRAMME

1

Ensure the ventilation system is running.  
Mount the big bag above the Hopper.



2

Open bottom closures.



3

Secure the bag to the Hopper  
to prevent spillage.



4

Product should discharge by gravity.




5

Elongate the bag by raising it slightly.



6

Shake all four corners of the bag vigorously  
as needed to minimize residue.



- Take care that the empty packaging is folded carefully and packed into another bag for disposal.
- Tightly close the bag between uses. When full, close and seal the outer bag and place in a shipping container for proper disposal, such as incineration or controlled landfill.

## 500 - 1000 Kg



The International  
Bromine Council



Responsible Care®  
OUR COMMITMENT TO SUSTAINABILITY



For further information: [www.bsef.com/vecap](http://www.bsef.com/vecap)  
BSEF Secretariat  
Rue Belliard 40, box 17, 1000 Brussels - Belgium  
+32 2 436 96 02 [info@bsef.org](mailto:info@bsef.org)

VECAP is a voluntary initiative of member companies of the International Bromine Council (BSEF)